



AUDIO AND VIDEO QUALITY CHECKLIST FOR LRPA PRODUCERS

AUDIO

Prior to recording on the JVC, LRPA recommends a final check of your audio. To do this, look at the mic settings, located on the *top left* of the JVC. **AUDIO SETTINGS SHOULD ALWAYS BE IN AUTO MODE.**

Consult photo # 1 below.

- Under **CH-2 INPUT**, the setting should always be set at **INPUT 1**
- Under **AUDIO INPUT**, the setting should always be set at **MIC + 48V** on **BOTH** lines
- Both **AUDIO SELECT** settings (**top and bottom**) should be set left to **AUTO**
- Please **do not adjust** the audio levels (the small wheels to the right of “AUDIO SELECT”)

If these settings have moved, make sure to re-set them as noted above.

Perform a quick audio check by snapping your fingers or speaking near the onboard mic.

YOU SHOULD SEE ALWAYS SEE AUDIO LEVELS ON YOUR PREVIEW MONITOR.



Photo #1: Mic Settings

Photo #2: ND Filter

VIDEO

Prior to recording on the JVC, LRPA recommends a final check of your video quality. To do this, look at the ND FILTER setting, located on the *left side of the JVC between the lens and the preview monitor*.

THE ND FILTER SHOULD ALWAYS BE SET TO OFF (the lowest setting). Consult photo # 2 above. If this setting has moved, make sure to re-set it to the lowest setting as noted above.